



ELODIE Collection

INTENDED USE: Swivel chair on 5-star aluminum base, adjustable in height, synchronized self-weighting mechanism, with armrests.

The main feature of the Elodie collection is the use of a brand new sound-absorbing backrest. The family of seats is versatile and suitable for use in operational and executive environments, thanks to the three heights of the backrest and the integrated synchronized mechanism.

MATERIALS UTILIZED: The collection is made with backrest in thermoformed polyester felt and seat in polyurethane foam upholstered, armrests and lower part of the seat in techno-polymer, gas column in steel, base in die-cast aluminum.

FINISHES: Slight differences in shades between different surfaces are possible. Furthermore, in the case of products purchased at different times, despite the use of durable materials for use in outdoor environments, natural-climatic factors can cause slight variations in shades.

CLEANING: To maintain the Gaber's techno-polymer products in perfect conditions through time and guarantee a long lasting quality of the raw materials we hereby recommend very basic care instructions to be followed. Techno-polymer surfaces usually need to be cleaned with a normal cloth and warm water; for the most persistent stains a small amount of liquid soap diluted in water may be used. We recommend to strictly avoid all types of abrasive substances, like for example powdered cleaning products, creams, score pads and rough sponges. Gaber's techno-polymer products can be sanitized using different substances, for more information check on the web "Polypropylene chemicals resistance compatibility"; the use of these substances also depends on the temperature, pressure and concentration. It is always a good practice, after sanitizing the techno-polymer products with these substances, rinse immediately the products with water.

Metal surfaces in steel and aluminum should be cleaned with a soft, damp cloth soaked in hot water. For stubborn stains, mild liquid soap can be diluted in water in moderation. Always dry after cleaning with a soft cloth. Do not use creams or pastes to clean metals, do not use chlorine, bleach or aggressive detergents. Do not use abrasive pastes or sponges that can scratch metal surfaces.

To clean the fabrics used by Gaber, consult the specific technical data sheet.

DISINFECTING: Gaber's techno-polymer products can be sanitized using the following list, in where resistance of the techno-polymer is emphasized to these substances on the side.

Techno-Polymer Chemical Compatibility: depends on temperature/pressure and concentration, important always no abrasive detergents.

Acetone – Excellent Resistance
Alcohols Ethyl and Methyl- Excellent Resistance
Ammonia – Excellent Resistance
Acqua Regia – Good Resistance, Minor Effect
Bleaching Liquors = Sodium hypochlorite 1% Excellent Resistance - Suitable
Bleach = Sodium hypochlorite 5% - 20° (68°F) Excellent Resistance - Suitable / 60° (140°F) Fair - Not recommended
Bleach = Sodium hypochlorite 10%-15% - 20° (68°F) Excellent Resistance - Suitable / 60° (140°F) Fair - Not recommended
Bleach = Sodium hypochlorite 20% - 20° (68°F) Excellent Resistance - Suitable / 60° (140°F) Fair - Not recommended
Bleach = Sodium hypochlorite 100% - 20° (68°F) Severe effects – Do not use
Calcium Carbonate – Excellent
Chlorine Aqueous – Saturated Solution 20° (68°F) Excellent Resistance - Suitable
Swimming Pool Free Chlorine residual Level: around 1 ppm (mg/l) 20° (68°F) Excellent Resistance - Suitable
Chloroform – Fair Resistance, moderate effect
Clorox (Bleach) – Excellent Resistance
Glycerin – Excellent Resistance

Sea Water – Excellent Resistance
Soap Solutions – Excellent Resistance

WARNING: This sheet complies with the provisions of the law and of April 10, 1991 n. 126 "Rules for consumer information" and with the Decree of February 8, 1997 n. 101 "Implementing Regulation".
This article has also passed a series of tests corresponding to the UNI EN 16139 AC: 2013 standard.